


Cool Cube™

Best Practices

Call for
Technical Support
(608) 526-6901



- Prep the PCM (phase change material) panels before use according to one of the described methods provided by VeriCor.
- Ensure all components are clean and free of damage.
- Lay panels flat when turning them solid (to disperse liquid throughout the panel).
- Enable ample air flow around all panel sides.
 - Use spacers (pencils) or racks. →
- Freezing/melting times vary depending on number of panels being prepped and equipment being used.
- Assemble using all six panels for maximum hold time.
 - Using less panels does not change the holding temperature, but does decrease the hold time.
- Panels are reusable (10,000+ cycles).
 - End-of-life disposal: Panels are a plastic #2, typically recycled by businesses/communities. PCM is nontoxic and readily biodegradable.
- Use a calibrated data logger or other temperature monitoring device to observe internal temperature.
- Avoid unnecessary opening of the Cool Cube™ after loading payload. Opening of the Cool Cube™ will decrease hold time.
- An infrared temperature thermometer can assist in ensuring the panels reach a safe pack-out temperature (good for finding out the approximate temperature of each panel).
- The farther the ambient temperatures are from the melting point, the quicker PCM will change states (solidify/liquefy).



Various methods based on type of panel, equipment available & purpose.

Cool Cube™ Refrigerator PCM Panels

for vaccine, blood, medicine & more.

All Sizes



Blue Tab/Label



PCM Panel for **REFRIGERATOR** temps
(3-6°C / 37-43°F)

Remove Prep (Freezer/Fridge/Room - See User Guide) Assemble Pack-Out Close

Part: CC-PCM-BV(s)
C/N:


Do not expose to extreme heat (275°C) or use abrasive cleaners.

tel: +1 608 526 6901
VeriCorMed.com/PCM

Video



Prep Method A: Freezer/Fridge Prep to keep product cold



DO NOT assemble panels directly from a freezer, as they may be initially below 0°C.

Panel Prep


- 2.1 Lay panels flat in a freezer** until all the PCM (phase change material inside the panel) turns solid. At -15°C/5°F the PCM will solidify in a couple hours.
- 2.2 Transfer panels into a fridge** at least 3 hours before use. Panels may be stored in the fridge until needed for assembly or until the PCM melts.*

* If a fridge maintains 4°C/39°F or below, the PCM within the panels will not melt (melting point is 4.5°C/40°F), which will keep the panel solid indefinitely until pack-out. If the fridge maintains 5°C/41°F or above, periodically check for melting and restart at step 2.1 to ensure optimal performance.

- 2.3 Shake panels to verify the PCM is solid.** If there is liquid, restart at step 2.1 to ensure the longest hold time. Using liquid PCM or panels with a solid/liquid combination decreases the hold time.



PCM Panel Shake Test



ISTA 7D Thermal Performance Study

Lab-Qualified Hold Times When Starting with Solid PCM

	Qualified Temps:	2-8°C	1-6°C	1-10°C
Cool Cube™ 03	Utilizing Six (6)	65 hrs	39 hrs	70 hrs
Cool Cube™ 08	Refrigerator Temp	76 hrs	53 hrs	83 hrs
Cool Cube™ 28	PCM Panels	103 hrs	68 hrs	108 hrs
Cool Cube™ 96	(Blue Tab/Label)	126 hrs	112 hrs	128 hrs

Times listed are based on lab-validated, 24-hour cycles of a summer profile (hot ambient temperatures) without the additional thermal mass of a payload, which if conditioned properly, will improve hold times. Actual performance times may vary.